


KARMA



JW452T
Round Two-Tone Bowl
4 1/4" dia. x 2 5/8" h., 12 oz.



JW4432T
Round Two-Tone Bowl
5 1/4" dia. x 3" h., 24 oz.



JW542T
Round Two-Tone Bowl
6 3/4" dia. x 3 1/2" h., 48 oz.



JW642T
Round Two-Tone Bowl
7 3/4" dia. x 4" h., 64 oz.



JW92T
Round Two-Tone Bowl
9" dia. x 2 1/2" h., 44 oz.



JW99R2T
Round Two-Tone Plate
9" dia. x 3/4" h.



JW552T
Square Two-Tone Plate
5" sq. x 3/4" h.



JW952T
Rectangular Two-Tone Plate
9" x 5" x 1" h.



JW1382T
Rectangular Two-Tone Plate
13" x 8" x 1" h.



JW3252T
Two-Tone Sauce Dish
3 1/4" x 2 1/2" x 1" h., 2 oz.



JWL11852T
Two-Tone Bento Box Lid
11 1/4" x 8 3/4" x 1" h.

JW11852T
Two-Tone Bento Box
10 3/4" x 8 3/8" x 2" h.



020-3 - Soup Spoon
5 1/2" L.
Also available in White (W) & Ebony Sand (ES),
not available in Red.



CH105 - Chop Sticks
10 1/2" L.
Available in Black Matte (BM), Black Gloss (BG)



KARMA



JW452T

Round Two-Tone Bowl
4 1/4" dia. x 2 3/8" h., 12 oz.



JW4432T

Round Two-Tone Bowl
5 1/4" dia. x 3" h., 24 oz.



JW32T

Round Two-Tone Bowl
6" dia. x 3 1/2" h., 32 oz.



JW542T

Round Two-Tone Bowl
6 3/4" dia. x 3 1/2" h., 48 oz.



JW642T

Round Two-Tone Bowl
7 3/4" dia. x 4" h., 64 oz.



JW92T

Round Two-Tone Bowl
9" dia. x 2 1/2" h., 44 oz.



JW99R2T

Round Two-Tone Plate
9" dia. x 3/4" h.



JW552T

Square Two-Tone Plate
5" sq. x 3/4" h.



JW952T

Rectangular Two-Tone Plate
9" x 5" x 1" h.



JW1382T

Rectangular Two-Tone Plate
13" x 8" x 1" h.



JW3252T

Two-Tone Sauce Dish
3 1/4" x 2 1/2" x 1" h., 2 oz.



JW11852T

Two-Tone Bento Box
10 3/4" x 8 3/8" x 2" h.

JWL11852T

Two-Tone Bento Box Lid
11 1/4" x 8 3/4" x 1" h.



020-3 - Soup Spoon
5 1/2" L.

Also available in White (W) & Black (B),
not available in Red.



CH105 - Chop Sticks
10 1/2" L.

Available in Black Matte (BM), Black Gloss (BG)



EBONY SAND (ES)