



PARTS MANUAL

V SERIES NON-INSULATED HOLDING & PROOFING CABINET

MODEL:

VHFA9 ML-138070

VHFA18 ML-138071

VP18 ML-138089



For additional information on Vulcan-Hart or to locate an authorized parts and service provider in your area, visit our website at www.vulcanequipment.com

Vulcan-Hart Food Holding and Transportation Cabinets are produced with quality workmanship and material. Proper installation, usage and maintenance will result in many years of satisfactory performance.

Before performing maintenance on the cabinet, thoroughly read the Service Manual and carefully follow all instructions in the order given. Refer to the Installation and Operation Manual for detailed operating instructions.

This manual is applicable only to models listed on the cover page.

To obtain Service and Parts information, contact Vulcan-Hart Service Department at the address listed on the front cover of this manual or refer to our website: www.vulcanequipment.com.

Technical Service 1-800-814-2028

Service Parts 1-866-628-0485

When calling for Technical Service or Parts, have the model number and serial number available.

VHFA - SERIES (LOW COST FORCED AIR)	
DESCRIPTION	VULCAN #
CASTER, 5" RIGID (THRU 12-31-09)	00-851800-00684
CASTER, 5" SWIVEL (THRU 12-31-09)	00-851800-00685
CASTER, 5" RIGID	00-960519
CASTER, 5" SWIVEL	00-960520
CLIP, ELEMENT	00-960525
CORD, FAN	00-960534
CORD, POWER 16/3 120V. 15 AMP (VHFA9)	00-961640
CORD, POWER 12/3 120V. 20 AMP (VHFA18)	00-960533
DOOR, GLASS (VHFA18 / VP18)	00-960558
DOOR, GLASS (VHFA9)	00-960559
ELEMENT, 120V - 600W (VHFA9)	00-960563
ELEMENT, 120V - 1000W (VHFA18)	00-961358
FAN, 120v. (4.75" x 4.75")	00-961086
GASKET, DOOR (VHFA9)	00-851800-00835
GASKET, DOOR (VHFA18/VP18)	00-960599
HINGE, PIVOT	00-960617
HOLDER, CORD	00-960532
HOLDER, PROBE THERMOMETER	00-851800-00029
HOLDER, PROBE THERMOSTAT	00-851800-00032
KNOB, THERMOSTAT	00-960644
LATCH, DOOR MAGNETIC	00-960664
LIGHT, INDICATOR DUAL 240V (THRU 9/30/16)	00-960671
RACK, SIDE	00-960702
SWITCH, FAN (THROUGH LATE 9/2016)	00-960727
SWITCH, ON/OFF (9/2016-PRESENT)	00-960937
THERMOMETER, DIAL	00-960736
THERMOSTAT	00-960741

VP18	
(NON-INSULATED PROOFER)	
DESCRIPTION	VULCAN #
CASTER, 5" RIGID	00-960519
CASTER, 5" SWIVEL	00-960520
CLIP, ELEMENT	00-960525
CORD, FAN	00-960534
CORD, POWER 12/3 120V. 20 AMP	00-960533
DOOR, GLASS (VP18)	00-960558
ELEMENT, 120V - 1000W	00-961358
FAN, 120V (4.75" x 4.75")	00-960589
FAN, 120v. (3.50" x 3.50")	00-960833
GASKET, DOOR (VHFA18 / VP18)	00-960599
HINGE, PIVOT	00-960617
HOLDER, CORD	00-960532
HOLDER, PROBE THERMOMETER	00-851800-00029
HOLDER, PROBE THERMOSTAT	00-851800-00032
KNOB, THERMOSTAT	00-960644
LATCH, DOOR MAGNETIC	00-960664
LIGHT, INDICATOR DUAL 240V	00-960702
PAN, PROOFER 12 X 10 X 2 1/2"	00-960693
SLIDES, TRAY	00-960753
SWITCH, HOLD/PROOF (THROUGH LATE 9/2016)	00-960725
SWITCH, FAN (THROUGH LATE 9/2016)	00-960727
SWITCH, HOLD/PROOF (LATE 9/2016 TO PRESENT)	00-960934
SWITCH, ON/OFF	00-960937
THERMOMETER, DIAL	00-960736
THERMOSTAT	00-960741