



Plate
 61100ST0100 D 12 1/2"
 61100ST0101 D 11 7/8"
 61100ST0102 D 11"
 61100ST0103 D 10 5/8"
 61100ST0104 D 10 1/4"
 61100ST0105 D 9"
 61100ST0106 D 8 3/8"
 61100ST0107 D 7 1/4"
 61100ST0108 D 6 3/8"



Coupe Plate
 61100ST0110 D 10 1/2"



61100ST0111
 Deep Pasta Plate D 11 1/2"
 61100ST0112
 Deep Bowl D 11"



Oval Winged Platter
 61100ST0115 L 15"



Oval Platter
 61100ST0113 L 14 1/2" W 10 3/4"
 61100ST0114 L 12 1/2" W 9 1/4"



Rim Rectangle Platter
 61100ST0116 L 14 1/2" W 10 3/4"
 61100ST0117 L 11 3/8" W 7"



Rectangle Platter
 61100ST0118 L 13" W 9"



Square Plate
 61100ST0119 L W 9 7/8"
 61100ST0120 L W 8 1/2"
 61100ST0121 L W 5"




Pasta Bowl
 61100ST0123 D 11 7/8"



Pasta Plate
 61100ST0122 D 11"
 61100ST0124 D 10 5/8"



Pasta Bowl
 61100ST0134 D 11"
 61100ST0127 D 9" (38 oz)



Trumpet Bowl
 61100ST0131 D 11"



Deep Bowl
 61100ST0126 D 8" (34 3/4 oz)



Square Pasta Bowl
 61100ST0146 D 9 3/4"



Rim Soup
 61100ST0125 D 9 1/4"



Cereal Bowl
 61100ST0128 D 5 1/2" (15 oz)



Square Bowl
 61100ST0132 Tall L W 4 3/4" (18 1/2 oz)
 61100ST0133 Low L W 4 1/2"



Fruit/Condiment
 61100ST0129 D 4 1/8"



Bouillon
 61100ST0130 D 2 1/4" (9 oz)
 Saucer
 61100ST0141 D 6"



Mug
 61100ST0140 (13 oz)



Mug
 61100ST0139 (12 oz)



Tall Cup
 61100ST0137 L 3" (9 1/2 oz)
 Saucer
 61100ST0141 D 6"



Stack Cup
 61100ST0136 L 2 3/4" (9 oz)
 Saucer
 61100ST0141 D 6"



Ad Cup
 61100ST0138 (3 1/2 oz)
 Ad Saucer
 61100ST0142 D 4 1/2"



Creamer
 61100ST0143 W 3 1/4" (10 oz)
 61100ST0144 W 2 3/4" (6 oz)



Sugar Pack Holder
 61100ST0145 L 3 3/4" W 2 3/4"