



Round Plate
61105ST0500 D 12"
61105ST0501 D 11"
61105ST0503 D 10 1/4"
61105ST0504 D 9"
61105ST0505 D 6 1/4"



Deep Plate
61105ST0509 D 11"
61105ST0502 D 10 1/4"
61105ST0510 D 8 7/8"



Square Plate
61105ST0506 L W 10 7/8"
61105ST0507 L W 8 1/2"
61105ST0508 L W 5 7/8"



Rectangle Platter
61105ST0511 L 13" W 9"
61105ST0512 L 11 3/8" W 6"



Square Deep Plate
61105ST0527
 L W 9 7/8" (49 oz)



Square Deep Bowl
61105ST0528 Salad
 L W 8" (67 3/8 oz)
61105ST0529 Soup
 L W 6 3/8" (27 7/8 oz)



Square Fruit Dish
61105ST0530
 L W 5 3/4" (15 7/8 oz)



Rectangle Dish
61105ST0513
 L 7 7/8" W 6 1/4"



Square Bowl
61105ST0526
 L W 3 1/2" (3 3/4 oz)



Bowl
61105ST0516
 D 8 1/2" (45 1/2 oz)



Soup/Cereal Bowl
61105ST0515
 D 6 1/4" (25 3/4 oz)



Fruit Bowl
61105ST0535
 D 5 1/4" (12 3/4 oz)



AD Cup
61105ST0536 (3 3/4 oz)
 AD Saucer
61105ST0538 D 4 3/4"



Stack Cup
61105ST0519 (8 3/4 oz)
 Saucer
61105ST0514 D 6 1/4"



Stack Mug
61105ST0532 (12 1/2 oz)



Teapot W/Lid
61105ST0520 (17 oz)



Sugar Bowl W/Lid
61105ST0524 (11 3/4 oz)



Creamer
61105ST0518 (5 oz)