



Plate
61110ST0700 L 12" W 10 1/4"
61110ST0701 L 9 1/4" W 7"
61110ST0702 L 6 3/4" W 6 1/4"



Plate
61110ST0709 L 10" W 6"



Platter
61110ST0705 L 16 1/8" W 9 1/4"
61110ST0706 L 13 3/4" W 7"
61110ST0708 L 13" W 7"



Tray
61110ST0704 L 16" W 4 3/4"



Pasta Bowl
61110ST0721
 L 11 1/4" (31 1/2 oz)



Rim Soup
61110ST0720
 L 8 3/4"



Salad Bowl
61110ST0719
 L 8 3/4" (55 oz)



Cereal Bowl
61110ST0717
 L 6 3/4" (22 oz)



Rice Bowl
61110ST0718
 L 4 3/8" (10 oz)



Fruit Dish
61110ST0716
 L 5 1/8"



AD Cup
61110ST0712 (3 3/4 oz)
 AD Saucer
61110ST0711 L 5" W 4"



Tea Cup
61110ST0713 (8 1/2 oz)
 Saucer
61110ST0710 L 6 3/4"



Coffee Cup
61110ST0714 (6 3/4 oz)



Mug
61110ST0715 (12 oz)



Creamer
61110ST0722 (6 1/2 oz)



Sugar Bowl W/Lid
61110ST0723 (6 oz)



Salt Shaker
61110ST0724
 Pepper Shaker
61110ST0725



Sauce Dish
61110ST0726 L 3 3/4"



Coffee Spoon
61110ST0727 L 5"