



Rim Square Plate
61103ST0418 L W 9 7/8"
61103ST0421 L W 8 1/2"
61103ST0423 L W 5"



Rim Rectangle Platter
61103ST0412 L 14 1/2" W 7"
61103ST0415 L 11 3/8" W 7"



Coupe Rectangle Platter
61103ST0413 L 14 1/4" W 8"
61103ST0414 L 12 5/8" W 7 1/2"




Rectangle Platter
61103ST0416 L 13" W 9"



Square Bowl
61103ST0428 L W 10" (120 oz)
61103ST0429 L W 7 1/2" (80 oz)
61103ST0430 L W 4 3/4" (18 oz)



Deep Bowl
61103ST0446
 D 8 1/4" (33 oz)



Deep Bowl
61103ST0440 D 9 5/8"
61103ST0441 D 8 1/8" (76 oz)



Soup/Noodle Bowl
61103ST0437 D 9" (50 oz)
 Noodle/Rice Bowl
61103ST0438 D 6" (24 oz)
61103ST0439 D 4 1/2" (9 oz)



Oval Salad Bowl
61103ST0436 D 9 1/4" (36 oz)
61103ST0442 D 8" (20 oz)
61103ST0443 D 6" (8 oz)



Square Bowl
61103ST0455 L W 4 1/2"



Covered Casserole
61103ST0435
 L 7 1/2" (10 3/4 oz)



Rectangle Dish
61103ST0451
 L 8 1/2" W 3 1/2"



3 Compartment Dish
61103ST0453 L 7 1/4"



Mug
61103ST0434
 L 4 7/8" (13 oz)



Coffee Cup
61103ST0432 L 4 1/4" (8 1/2 oz)
 Saucer
61103ST0431 D 6"



Tea Cup W/Out Handle
61103ST0433
 L 3" (3 1/2 oz)



Tea Pot W/Lid
61103ST0447 L 9" (35 oz)
61103ST0448 L 7 5/8" (21oz)



Soup Spoon Small
61103ST0445 L 5"



Sauce Dish
61103ST0452 D 4" (4 oz)
 Soy Sauce Dish
61103ST0454 D 2 3/4" (2 oz)



Rectangle Sauce Dish
61103ST0450
 L 4" W 2 3/4"