



Plate
62101ST0640 D 12 3/8"
62101ST0641 D 11"
62101ST0642 D 10 1/4"
62101ST0643 D 9"
62101ST0644 D 8 1/4"
62101ST0645 D 6 3/8"



Deep Plate
62101ST0646 D 11 3/8"
62101ST0647 D 10 3/8"



Oval Platter
62101ST0649 L 15" W 12"
62101ST0650 L 13 1/8" W 10 5/8"
62101ST0651 L 11 1/4" W 8 7/8"
62101ST0652 L 9 1/4" W 7 1/4"



Square Rim Plate
62101ST0653 L W 9 7/8"
62101ST0654 L W 8 1/2"



Square Coupe Plate
62101ST0655 L W 9 1/8"
62101ST0656 L W 8 1/4"
62101ST0657 L W 6 3/16"



Pasta Bowl
62101ST0676 D 12"



Rim Soup
62101ST0673 D 9 1/4"



Oval Bowl
62101ST0674 L 12 3/4"
62101ST0675 L 9 1/4"



Salad Bowl
62101ST0670 D 8 3/8"
62101ST0671 D 7 1/4"
62101ST0672 D 6 1/4"
 Cereal Bowl
62101ST0669 D 5 1/8" (15 oz)



Fruit Dish
62101ST0668
 D 5 1/2" (8 oz)



Tea Cup
62101ST0661 (7 1/2 oz)
 Saucer
62101ST0658 D 6"



Cup
62101ST0662 (8 3/4 oz)
 Saucer
62101ST0658 D 6"



Stack Cup
62101ST0663 (8 1/2 oz)
 Saucer
62101ST0658 D 6"



Stack Mug
62101ST0665 (10 oz)



Bouillon
62101ST0666 Handled (9 1/2 oz)
62101ST0667 U/H D 3 3/4" (9 oz)
 Saucer
62101ST0658 D 6"



AD Tall Cup
62101ST0660 (3 1/2 oz)
 AD Saucer
62101ST0659 D 4 7/8"



AD Stack Cup
62101ST0664 (3 1/4 oz)
 AD Saucer
62101ST0659 D 4 7/8"



Creamer
62101ST0679 (10 oz)
62101ST0680 (5 oz)
 Creamer U/H
62101ST0681 (1 3/4 oz)



Coffee Pot
62101ST0698 (20 1/4 oz)



Tea Pot W/Lid
62101ST0684 (25 1/2 oz)
62101ST0683 (12 oz)
 Lid
62101ST0689 (Fits 0683)



Gravy Boat
62101ST0677 (12 oz)
62101ST0678 (6 3/4 oz)



Butter Dish
62101ST0682 D 3 3/8"



Sugar Bowl W/Lid
62101ST0686
 D 5 1/4" (6 oz)



Sugar Packet Holder
62101ST0685
 L 4 1/8" W 2 3/4"



Salt Shaker
62101ST0687 D 2 3/4"
 Pepper Shaker
62101ST0688 D 2 3/4"