



Presentation Plate
6305P600 D 11 7/8"




Plate
6305P601 D 11 1/4"
(Plate Cover 5379S792)
6305P602 D 10 5/8"
(Plate Cover 5379S802)
6305P603 D 9 1/2"
6305P604 D 8 1/4"
6305P605 D 6 1/4"



Coupe Presentation Plate
6305P696 D 11 3/4"



Presentation Plate Wide Rim
6305P699 D 11 3/4" (6 1/4" Well)



Square Plate
6305P690 L W 11 7/8"
6305P691 L W 10 5/8"
6305P692 L W 9 1/2"
6305P693 L W 8 1/4"
6305P694 L W 6 3/4"
6305P695 L W 6"



Rim Pasta Plate
6305P698
D 11 3/4" H 2 1/8" (13 3/4 oz)



Rim Soup Plate
6305P697
D 9 1/2" H 2 1/8" (7 1/2 oz)



Pasta Plate
6305P668
D 10 1/4" H 1 3/4" (16 oz)



Soup Plate
6305P667
D 9" H 1 5/8" (11 3/4 oz)



Stackable Bowl
6305P664 D 5 3/4" H 2 3/8" (21 1/4 oz)
6305P665 D 4 7/8" H 2 1/8" (14 1/2 oz)
Underliner
6305P666 D 8 1/4"



Bouillon Cup
6305P663 D 4" H 2 1/2" (11 1/4 oz)
Cream Soup Bowl Handled
6305P662 L 6" H 3 7/8" (11 1/4 oz)
Saucer
6305P673 D 7 1/8"



Coffee Cup
6305P670 L 4 1/8" H 2 3/4" (6 3/4 oz)
Coffee Saucer
6305P671 D 6 1/8"



Breakfast Cup
6305P672 L 5" H 2 1/2" (11 1/4 oz)
Breakfast Cup Saucer
6305P673 D 7 1/8"



AD Stack Cup
6305P674 L 3 3/8" H 2 1/2" (3 oz)
AD Saucer
6305P675 D 5"



Stack Mug
6305P676
L 4 3/8" H 3 7/8"
(10 3/4 oz)



Creamer
6305P680 L 5 1/8" H 3 1/8" (8 1/2 oz)
6305P681 L 4 1/2" H 2 3/4" (5 oz)
6305P682 L 3 3/4" H 2 1/4" (3 oz)