



Square Plate
6940E606 L W 12"
6940E604 L W 10"
6940E603 L W 6"
6940E658 L W 8"



Square Plate
6940E6047 L W 9"
6940E6031 L W 7"
6940E619 L W 6 1/4"
6940E6046 L W 4 1/2"



Rectangle Tray
6940E610 L 14 1/2" W 6 1/2"
6940E6089 L 13 1/2" W 10 1/2"
6940E656 L 13" W 7 1/2"
6940E663 L 10 5/8" W 6 1/2"




Serving Stand
5379S799
L 10 1/2" W 7" H 14 1/2"
(For 6940E663)



Oblong Tray
6940E661 L 14" W 8"
6940E660 L 14" W 6"
6940E659 L 14" W 4"



Oblong Tray
6940E602 L 10" W 8"
6940E601 L 10" W 6"
6940E600 L 10" W 4"



Curved Rim Rectangle Tray
6940E665 L 13" W 6 1/2"
6940E657 L 11 1/2" W 5 1/2"
6940E666 L 10" W 4 3/4"
6940E667 L 8" W 3 3/4"



Oval Tray
6940E6043
L 7 1/4" W 5 1/8" H 1"



Square Bowl
6940E613
L W 8" H 2 3/8"
(32 oz)



Square Bowl
6940E662 L W 5 1/4" H 2 1/4" (18 oz)
6940E669 L W 4 3/4" H 2" (13 oz)
6940E668 L W 4" H 1 3/4" (7 3/4 oz)



Square Ramekin
6940E616
L W 3 1/8" H 1 1/8"
(2 3/4 oz)



Tall Mug
6940E6019 L 4 1/4" H 4 3/8" (10 oz)
6940E6018 L 4 1/8" H 4 1/8" (8 oz)
6940E6017 L 3 1/8" H 2 7/8" (3 oz)



Mug
6940E686
L 4 5/8" W 3 1/2" H 3 5/8"
(9 1/2 oz)