



Teapot Flat Sided
A100P005 (12 oz) (Clear glaze)
 Lid for Teapot
A100P012 (Clear glaze)



Allegheny Creamer
A100P082
 L 3 1/2" H 3" (3 1/2 oz)
 (Clear glaze)



Astro Creamer
A100P080
 L 2 3/8" W 2 1/4"
 (2 3/8 oz)



Oval Rarebit
A100P151 L 11 3/4" W 5 3/4" (15 oz) (Clear glaze)
A100P152 L 10" W 5" (12 oz) (Clear glaze)
A100P153 L 8 3/4" W 4 1/8" (8 oz) (Clear glaze)
A100P154 L 7 7/8" W 3 3/8" (4 1/2 oz) (Clear glaze)



Oval Baker
A400P157
 L 5 3/4" W 4" H 1 7/8"
 (8 oz) (Polar white)



Fry Pan Server
A100P001 L 8 1/4" W 7 3/4" H 1 3/8" (18 oz)
 Handle 3"
 (Clear glaze)



Shirred Egg Dish
A100P002 D 7 3/4" (23 oz)
 (Clear glaze)



Handled Casserole/Tab Soup
A100P010 D 5 3/4" H 1 7/8" (11 oz)
 Handle 1 5/8" (Clear glaze)
A100P011 D 4 7/8" H 1 7/8" (7 oz)
 Handle 1 1/4" (Clear glaze)



Celery Tray
A100P004 L 10" W 4 3/4" H 1 1/8"
A100P003 L 7 5/8" W 3 1/2" H 1 1/8"



Ramekin
A100P302 D 2 7/8" H 1 1/2"
 (2 1/2 oz)



Sugar Packet Holder
A100P389 L 3 1/2" H 2 3/4"
 (6 oz) (Clear glaze)



Sugar Bag Bowl
A100P090 L 4 7/8" W 3 1/4" H 2"
 (6 oz)



Divided Condiment Dish
A400P075 L 7 1/2" W 2 1/4"
 (1 oz Each Well) (Polar white)