

Coupe Plate
6900E439 D 11 3/4"
6900E440 D 10 1/4"
6900E441 D 8"
6900E442 D 5 3/4"




Form Plate
6900E572 D 9"
6900E573 D 5 3/8"



Oval Coupe Plate
6900E410 L 10" W 7 1/2"
6900E409 L 8" W 6"
6900E408 L 6 1/2" W 4 3/4"



Oval Bowl
6900E588 L 10" W 6 1/4" H 2 3/4" (30 oz)
6900E587 L 8" W 5" H 2 1/4" (15 1/2 oz)
6900E586 L 6" W 3 3/4" H 1 3/4" (7 oz)
6900E585 L 4" W 2 1/2" H 1 1/8" (1 3/4 oz)



Romano Bowl
6900E562
 D 8" H 4" (38 oz)




Cereal Bowl
6900E517
 D 7" H 2 1/8" (16 oz)



Rice Bowl
6900E550
 D 5 1/2" H 2 1/2" (16 oz)
6900E551
 D 4 1/4" H 2" (8 oz)



Bouillon Cup
6900E428
 D 4" H 2 1/4" (7 1/2 oz)
 (Fits E530)



Form Fruit Dish
6900E575
 D 4 3/8" H 1 1/2" (4 3/4 oz)



Oval Tray
6900E401 L 7 1/4" W 5 1/8"
6900E402 L 6 7/8" W 3 1/2"



Symphony Cup
6900E509 L 4 3/8" H 3" (7 oz)
Saucer Double Well
6900E530 D 6 1/4"



Coupe Mug
6900JH6056
 L 5 1/4" H 4 1/8" (15 1/2 oz)



Mug
6900E438
 L 4 3/4" H 4 3/4" (12 oz)
6900E584
 L 4" H 4 3/8" (10 oz)



Form Mug
6900E437 W 4 3/4" H 3 7/8" (13 oz)
6900E574 W 4 1/2" H 3 3/4" (9 oz)
Saucer Double Well
6900E530 D 6 1/4" (Fits E437, E574)