



Oval Serving Bowl  
6900E426 L 14" W 9" H 3 1/4"  
6900E425 L 12" W 7" H 2 3/4"



Square Serving Bowl  
6900E576 L W 10 1/8" H 3 7/8" (119 oz)  
6900E577 L W 6 7/8" H 3 7/8" (51 oz)



Olive Tray  
(Elongated Oval Tray)  
6900E561 L 12" W 1 3/4"



Shirred Egg  
6900E434 L 8 1/4" W 6 5/8" H 1 1/2" (16 3/4 oz)  
6900E435 L 7 3/8" W 6 1/4" H 1 1/2" (12 oz)  
6900E436 L 6" W 5" H 1 1/2" (7 3/4 oz)



Rarebit  
6900E546 L 11" W 6 1/4" (24 oz)  
6900E547 L 9" W 5" (8 oz)



Oval Baker  
6900E527 L 9" W 6 1/4" (16 oz)  
6900E528 L 6 1/2" W 4 3/8" (8 oz)



Oval Dish  
6900E589 L 5 3/8" W 3 3/4" H 1 3/8"  
(6 1/2 oz)



Crème Brulee  
6900E552 D 4 3/4" (4 oz)



Sugar Packet Holder  
6900E525 L 3 3/8" W 2 5/8" H 2 3/8"



Creamer  
6900E526  
W 3 3/8" H 2 7/8" (5 oz)



Creamer  
6900E581  
W 1 3/4" H 1 3/4" (1 oz)



Large Sake Pourer  
6900E564  
H 5 5/8" (5 oz to Neck)



Sake Cup  
6900E565  
D 2" H 2" (2 oz)



Ramekin  
6900E431 D 4 3/4" H 2 1/4" (14 oz)  
6900E432 D 4 1/2" H 2" (9 oz)  
6900E548 D 3 1/2" H 1 1/2" (4 oz)  
6900E549 D 2 5/8" H 1 1/4" (2 oz)



Round Deep Ramekin  
6900E591  
D 3 1/8" H 2" (5 1/2 oz)  
6900E592  
D 2 1/4" H 1 3/4" (2 oz)



Square Ramekin  
6900E568 L W 4" H 1 1/4" (5 1/2 oz)  
6900E567 L W 3 1/8" H 1 1/8" (2 3/4 oz)  
6900E566 L W 2" H 1" (3/4 oz)



Square Ramekin  
6900E421 L W 3 1/4" H 1 5/8" (6 3/4 oz)  
6900E422 L W 2 1/4" H 1 1/4" (2 1/4 oz)



Square Deep Ramekin  
6900E593 L W 2" H 1 7/8" (3 oz)  
6900E594 L W 1 5/8" H 1 1/8" (1 oz)



Square Sauce Dish  
6900E544 L W 4 1/2" (2 1/2 oz)  
6900E545 L W 3" (1/2 oz)



Double Well Rectangle Tray  
6900E595 L 5 3/4" W 2 7/8"  
(2 oz Each Well)