

Cubol Dish Dimple Deep **6527B810** L W 11 1/2" H 2 7/8"



Clear Duo Plate 6527B609 L W 8"



Clear Quad Plate 6527B615 L W 10 1/2"



Clear Tri Plate 6527B608 L 13 1/2" W 5"




Clear Curved Square 6527B661 L W 10"



Rectangle Deep **6527B603** L 12 1/2" W 5"



Square with Oval Well 6503G068 L W 6 3/4"




Rectangle 3 Compartment Deep Tray **6506G201** L 11 5/8" W 5 7/8" H 3/4"



Rectangle 4 Compartment Tray **6506G208** L 11 3/4" W 5 7/8"



Rectangle W/Square Center Tray 6506G203 L 12" W 9"




Rectangle Centered Tray **6506G202** L 11 3/4" W 9"



Square 9 Compartment 6506G205 L W 12"



Float **6506G244** D 11" (5" Well) (8 oz)



Rectangle Ripple Plate 3 Compartment 6506G249 L 12 1/2" W 6 3/4"



Square Ripple Plate 6506G250 L W 9 1/2"



Charger Plate 6506G231 L W 12"



Organics Glass Plate 6527B710 L 14"



Pearl Bowl 6527B814 D 7"



Curved Square Small 6505G364 L W 5"



Dip Dish 6527B673 L W 3 3/4"



Clear Butter Dish 6527B510 L W 4"