



Coupe Plate
11070565 D 11 3/4"
11070544 D 11"
11070566 D 10"
11070543 D 9"
11070567 D 8"
11070568 D 6"



Spice Plate
11070579 L 12" W 10 1/4"
11070580 L 10" W 9"
11070581 L 8" W 7"
11070582 L 6" W 5 1/8"



Zest Platter
11070585 L 12" W 10 1/4" H 2 1/8"
11070586 L 10" W 9 1/2" H 2"
11070587 L 8" W 7 3/4" H 1 3/4"



Oval Platter
11070605 L 14 1/4" W 10 1/4"



Relish Oval
11070572 L 12"
11070573 L 9"



Square Plate
11010407 L W 11 1/4"
11010408 L W 9"
11010409 L W 7"



Square
11070553 L W 10 1/2"
11070619 L W 7 1/2"
11070620 L W 6 1/2"
11070621 L W 4"




Rectangle Platter
11070551 L 13 1/2" W 10 5/8"



Rectangle Platter
11070552 L 14 1/2" W 6 1/2"
11070556 L 12 1/2" W 7 1/2"
11070549 L 11 3/8" W 5 1/2"
11070550 L 10 5/8" W 6 1/2"
11070618 L 8" W 4"



Serving Stand
5379S799
 L 10 1/2" W 7" H 14 1/2"
 (For 11070550)



Coupe Bowl
11070545 D 11 1/2" (65 oz)
11070569 D 10" (38 oz)
11070570 D 8 1/2" (27 oz)
11070571 D 5" (4 oz)



Square Bowl
11010414 L W 10 1/4" (10 oz)
11010415 L W 9" (8 1/4 oz)
11010416 L W 7 3/4" (7 1/2 oz)



Taster Tray
11070577 L 10" W 5"



Stack Tray
11070559 D 8" (44 oz)
11070560 D 6 1/2" (21 oz)
11070561 D 5 1/2" (10 1/2 oz)
11010470 D 4" (4 oz)
11010471 D 3" (2 oz)



Tulip Bowl
11070542 D 8 3/4" H 4 1/4" (67 oz)
11070541 D 7" H 3 1/4" (36 1/2 oz)
11070540 D 5 1/2" H 2 3/4" (18 3/4 oz)
11070539 D 4" H 2" (6 3/4 oz)
11070538 D 2 3/4" H 1 1/4" (2 1/4 oz)



Casual Square Bowl
11070601 L 10" (68 oz)
11070602 L 8" (32 oz)
11070603 L 6" (12 oz)
11070604 L 4" (4 oz)



Essence Bowl
11070596 D 8" (30 oz)
11070597 D 6 1/2" (19 1/4 oz)
11070598 D 5 1/2" (11 1/2 oz)
11070595 D 4 1/2" (5 oz)



Angled Bowl
11070562 D 8" (24 oz)
11070563 D 6" (10 oz)
11070564 D 4" (2 1/2 oz)



Scoop Bowl
11070574 L 6 1/2" (9 oz)
11070583 L 4 1/2" (2 1/2 oz)
11070584 L 3 1/2" (1 oz)



Large Soup Bowl
11070558 D 4 1/2" H 3 1/2" (21 oz)
Saucer Double Well
11010225 D 6 1/2"



Tilt Pot
11070599
 D 3 1/2" H 3"
 (8 oz)