



1. Leg/Caster Installation

- Position unit so the leg cup is visible. NOTE – Team lift when necessary.
- Position legs or casters over the leg cup and attach with provided hardware.
- Stand the unit back up.



2. Level Unit


- Level the unit by turning the adjustable bullet feet.



Adjustable bullet feet

3. Cam Lock Removal

- If the cam lock is visible on the end of your line-up and will not be sealed against a wall, the cam lock must be removed to meet sanitary requirements.
A) Remove the 2 screws holding the lock in place.
B) Remove the cam lock.



A. Remove 2 screws

B. Remove cam lock

4. Field Joints

- Field joints should be installed with the units firmly held together, aligned, and sealed with approved sealant.

5. Service Connections

- Any unit with a drain must be installed to meet the federal, state, and local plumbing requirements.

IMPORTANT!
Unit must be installed in conformance with applicable federal, state and local plumbing codes, including adequate backflow protection when required